

EN Operating / Care instructions Diago 504

1. Operating instructions

DIAGO 504 is an electrically operated lifting and lowering system for installation of new or existing wall cabinets. The lift is a diagonal lift which lowers the cabinet down and forward in an arc-shaped motion to the front edge of the working area.

1. Press and hold the button to start the operation.
2. Release the button when the cabinet is at the desired level.

Pos. 1

The lift is equipped with safety trip panels which guarantee safe operation with no risk of being crushed.

Pos 2.

Variants of buttons for up / down operation.



2. Maintenance

The Diagonal lift is maintenance-free. Greasing and other actions are made during the manufacturing for the lifetime of the Diagonal lift. From safety point of view however some components shall be inspected each year.

- Inspections, service and repair work shall be made by competent persons.
- Remove the objects from the cabinet before maintenance and repair works are made.

3. Functional test

After installation a complete functional test with full load shall be made:

- Run the cabinet lift down and up all the way to respectively end position. Check that it moves freely, without hindrance and jarring sounds.
- Check that no cables are jammed. Check that the trip panel works under the entire surface. Test in particular with point loads and in which way a water tap on the worktop influences the safety trip panel operation.

4. Cleaning

Clean with lukewarm water and a non-scratching detergent containing soap or similar. Use a soft cloth or similar. After cleaning the surfaces shall be dried to avoid lime deposits.

**Scratching detergents or tools e.g. steel wool may not be used.
Consider that the product contains electrical components.**

5. Service & maintenance records

Order	Serial	Date
Date	Date	
Sign	Sign	
Remarks	Remarks	
Date	Date	
Sign	Sign	
Remarks	Remarks	