

EN Troubleshooting Guide Unilift 870

Products

UNILIFT 870

The Kitchen appliance lift is designed and tested to achieve optimum operation reliability and long life, provided that the operation, maintenance and inspections are carried out in accordance with the prescribed instructions. If in spite of this a fault appears you can get guidance about what to do according to the fault finding list below.

Remove the load from the platform before fault finding and repair work is carried out. Fault finding, service and repair work shall be made by competent persons only.

If any problem remains after you have taken actions in accordance with the list below you must contact a competent technician or your supplier.

Symptom	Action
The machine does not move when a control signal is given	<p>Check that the fuse for the mains feed is not damaged.</p> <p>Check that the mains plug is connected.</p> <p>If the Kitchen appliance lift still does not move contact an authorized technician and/or your supplier.</p> <p>This shall as first action, after above check points, check that all cables are connected and undamaged, and that the green light on the control box is lighting.</p> <p>If it is not lighting the control box is probably defect. Order a new unit from Granberg.</p>