

EN Operating / Care instructions InDiago 510

1. Operating instructions

InDiago is an electrically operated lifting system which lowers an internal cabinet down and forward in an arc-shaped motion to the front edge of the working area.

1. Press and hold the button to start the operation.
2. Release the button when the cabinet is at the desired level.

Pos. 1

The lift is equipped with safety trip panels which guarantee safe operation with no risk of being crushed.

Pos 2.

Variants of buttons for up / down operation.



2. Maintenance

InDiago 510 is maintenance-free. Greasing and other actions are made during the manufacturing for the lifetime of the product. From safety point of view however some components shall be inspected each year.

- Inspections, service and repair work shall be made by competent persons.
- Remove the objects from the cabinet before maintenance and repair works are made.

3. Functional test

- Test the lift unit up and down all the way to the respective end positions. Make sure the cabinet is running free without obstacles, crushing and noise. Make sure it remains in the lower and upper positions respectively.
- Make sure that no cables are clamped and fixed.
- Move the cabinet insert downwards and make sure that the clamp cover under the cabinet insert works by pushing it lightly. The cabinet insert should stop immediately and turn upwards to release space, an acoustic signal indicates that the clamp guard is activated.
- Check that the doors are opened and closed properly.
- Check that the cabinet fixing at the wall is intact.
- Check that lifting systems fixing points are intact in the wall cabinet.

Built-in safety system

- If the doors can not be opened all the way, the cabinet insert is prevented from running outwards.
- If someone push the doors in an attempt to close the doors during operation, the motion stops immediately and a beep sounds.
- If the cable to the motor unit is damaged or disconnected, the device stops and a beep indicates errors.

4. Cleaning

Clean with lukewarm water and a non-scratching detergent containing soap or similar. Use a soft cloth or similar. After cleaning the surfaces shall be dried to avoid lime deposits.

**Scratching detergents or tools e.g. steel wool may not be used.
Consider that the product contains electrical components.**

5. Service & maintenance records

Order	Serial	Date
Date	Date	
Sign	Sign	
Remarks	Remarks	
Date	Date	
Sign	Sign	
Remarks	Remarks	