

EN User manual Baby changing table 327 / Washing bench 328



EN Products

Daycare Changing Tables - Fixed height

Changing Table Granberg 327

Changing Table Granberg 327 - Laundry sink

Washing Bench Granberg 328

1. Introduction
2. Intended use
3. Technical data
4. Safe use
5. Load distribution and side forces
6. Instructions for recycling

1. Introduction

We have the pleasure to deliver a Baby changing table / Washing bench with fixed height.

Only authorized persons may use the product!

Authorization means obligation to read and follow the instructions.

It is very important that you read and understands the instructions before you use the device.
If you have any questions - contact your supplier.

This Instruction manual shall be available for all concerned persons, be kept in a protected place and shall follow the product, if it is moved to another installation site or another house or apartment owner.

Correct use, operation, inspections and maintenance are decisive for efficient and safe work.

2. Intended use

Model 327 is intended to be used as a changing area for small children. Model 328 is intended to be used as a washing bench in connection to a changing table.

The operation shall be indoors under normal housing conditions regarding temperature, humidity and lighting.

It is absolutely forbidden for persons to stand on extended wire baskets.

3. Technical data

	327	328
Installation	Freestanding (Fixed to the wall)	Freestanding (Fixed to the wall)
Total depth	800 / 1400 mm	620 mm
Totaldjup	800 mm	800 mm
Width, mattress	800 mm: 710 mm 1400 mm: 750 mm	--
Depth, mattress	710 mm	--
Border height	50 alt. 200 mm	--
Weight	800 mm: 20 kg 1400 mm: 40 kg	25 kg
Max. Load*	50 kg	50 kg

* Distributed load on the table

4. Safe use

The changing table is designed to avoid the risk of injury and accident. However, it is still most important that the user is thoroughly familiar with the correct manner of installing and operating the table.

- The changing table must only be used under the conditions described in "Intended use".
- It is absolutely forbidden for persons to stand on extended wire baskets.
- The table must be operated in a manner to avoid the risk of personal injury and material damage.
- The table must only be operated by persons who have read and understand these instructions and who are qualified to use it.
- Remember that it is your responsibility as user to ensure that nobody suffers injury.
- The changing table and the work area must be in good condition. The changing table must not be used in case of any damage or fault which affects its operational reliability or safety or if it has been repaired, modified or adjusted without the permission and approval of an authorised person.
- Modifications of the changing table which impact on its operational reliability or safety are not permitted.
- Plates and markings must not be removed or obliterated.
- Do not overload the changing table.
- The changing table must undergo annual inspection in the interests of accident prevention.
- The changing table surface must be clear during inspection, servicing and repair.
- Installation, service and repairs may only be carried out by persons possessing the necessary skills.
- Only original parts may be used as replacements, otherwise our warranty commitments may be null and void.

5. Load distribution and side forces

Note that the maximum load refers to a load which is spread and distributed evenly over the changing table surface. Point loads are not permitted.

Essential requirements for load distribution:

- **The load must be spread over the entire changing table surface.**
- **Lateral forces are not permitted.**

Lateral (sideways) forces can be caused e.g. by pressing against the changing table or the load.

6. Instructions for recycling

The product is manufactured from re-usable materials or from materials that can be recycled.